

Image Formation




A simple Formation Model




$$F(x,y)=i(x,y)*r(x,y)$$

Objects
Reflectance $0 \le r(x,y) \le 1$



The main components of a digital camera are: Iris, lens, shutter, and sensor.



The iris controls the aperture of the camera, determining the amount of light that reaches the sensor.

Capturing Different Amounts of Light





Large Aperture







Medium Aperture Small Aperture










The opening of the aperture is measured using the fnumber (f-stop); the diameter of the aperture is determined by the focal length divided by f-stop number.



Calculate the diameter of the aperture if we are using lens with focal length of 50 mm and aperture of f/2.8.

What about an aperture of f/1.4?

$$Area_{f/2.8} = \pi * (50/(2.8*2))^2 = 250.44mm^2$$

 $Area_{f/1.4} = \pi * (50/(2*1.4))^2 = 1001.54.44mm^2$

There is a difference of two stops between f/1.4 and f/2.8.








Shallow depth of field (large aperture)



Large depth of field (small aperture)

The opening or closing of the iris (aperture) also controls the depth of field, it refers to the amount of the image that is sharp.



Smaller Depth of Field(shallow)



Some common values for landscape images: f/8, f/11, or f/16




Some common values for portrait images: f/1.4, f/2, or f/2.8






Some common values for landscape images: f/8, f/11, or f/16







The lens focuses light onto the sensor. The focal length is the distance from the point where all the light rays converge inside the lens (optical center) to the sensor.




AOV: Angle of view





$$\frac{H}{Focal Length} = \frac{FOV}{Length \ of \ work}$$



Focal length ↑ AOV ↓ Magnification ↑







The shutter regulates the length of time that the light is admitted through the lens to the sensor (shutter speed). The shutter speed can be as fast as 1/10,000 of a second or as slow as several minutes.

Capturing Different Amounts of Light








Low shutter speed

Medium shutter speed

High shutter speed



Fast shutter speeds have the effect of freezing motion in the scene. Conversely, slow shutter speeds will blur motion in a scene.

Shutter Speed





1/500 sec

1/8 sec

Shutter Speed








Image Sensing

Incoming energy (e.g. light) lands on a sensor material responsive to that type of energy, generating a voltage. Collection of sensors are arranged to capture images.





Array of Image Sensors